


MULTIPOINT INDICATION SYSTEM

Dimensions (in mm):








Specials:

- Miniature panel inserts for thermocouple inputs at rear.
- Standard panel inserts for thermocouple inputs.

NOTE: 12, 18 and 23 points will have in that case a larger size housing (288 x 96 mm).

- 2,5 meter power cord with plug.
- 6 or 12 miniature panel inserts at front.
- 3HE high 19" rack mounting plate.
- 3HE high 19" rack mounting plate with 2 panel cutout for SWT-11000.
- Power on/off switch at rear or at front.
- 24 points without off.
- Other number of points, up to 24 points maximum.



Rear panel of a SWT-11006-...x-Indicator-special with a 6 standard jack inserts in correct calibration. Power connection (L, N, earth) with screw terminals, output, screw terminals.

Tel.: +31 (0)182 – 302 850 Fax: +31 (0)182 – 302 777 E-mail: info@thermo-electric.nl Internet: http://www.thermo-electric.nl

J/315r